Intel PRO/1000F™ LAN Card Driver

Installation Notes

These Installation Notes provide information on installing the Intel PRO/1000F LAN card driver in systems running Windows 2000®, Windows NT® 4.0 or Novell® NetWare® Operating Systems.

> ***Note:*** The enclosed Intel CDROM is included for documentation purposes only.

Driver Installation

NEC has provided validated Intel drivers for your operating system. The drivers required for the PRO/1000F LAN card are located on diskettes included with your LAN card.

- For Microsoft Windows 2000, use the enclosed diskette labeled *PRO/1000F Windows 2000 Drivers* to install PRO/1000F drivers.
- For Microsoft Windows NT, use the enclosed diskette labeled *PRO/1000F NT4 Drivers* to install PRO/1000F drivers.
- For Novell NetWare, use the enclosed diskette labeled *PRO/1000F NetWare Drivers* to install PRO/1000F drivers.

Trademarks

PRO/1000F is a trademark of Intel Corporation.
Novell and NetWare are registered trademarks of Novell, Inc.
Windows 2000 and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks belong to their respective owners.

455-01620-000
6/01